User Manual

T8/T8-2 Control unit
Loading of designs via network using bar code control

02440V10 [D] - 2018

Subject to change!
Änderungen vorbehalten!

© ZSK Stickmaschinen GmbH

Printed in Germany

[D] 02440V10

T8-Loading of designs via network using bar code control

Basics

Download Software-Updates:
https://www.zsk.de/t8-software.html

Requirements

- Bar code scanner with USB-access.
- With the **machine off**, connect the scanner to the back of a USB port on the T8 control unit. If necessary, set the scanner to ***Add return***.
- T8-2 Release 16.04.2018 (available for machines with MCP35 and MCP31 only, also CON-Modul respectively ARM-Modul).
- Established network connection for loading designs via network.

NOTICE

All discribed functions of the control unit T8-/T8-2 will be started at the Base Screen (BS).

The keys used in the function descriptions are shown in the above T8-/T8-2-figure.

Software settings

With the function ***Loading designs via network using bar code control*** of the T8 control unit, designs can be loaded into the machine via barcode scanner from a network-shared directory.

Variant 1: No modification options



Switch on the function ***No modification options***. Starting from the base screen of the T8 control unit, press the following buttons:

- **[L7]** ***Software-/hardware settings***
- **[R4]** ***Software settings***
- **[L3/R3]** ***No modification options***
- If the function is not yet displayed in the dialog, press the button **[L3 / R3]** and select the option **[L2 / R2]** ***No modification options*** in the dialog ***Modification options while design loading***.



If the button ***No modification options*** is active, the modification dialog will be switched off and will not appear when loading a design.

Variant 2: All modification options



Switch on the function ***All modification options***. Starting from the base screen of the T8 control unit, press the following buttons:

- **[L7]** ***Software-/hardware settings***
- **[R4]** ***Software settings***
- **[L3/R3]** ***All modification options***
- If the function is not yet displayed in the dialog, press the button **[L3/R3]** and select the option **[L2/R2] All** ***modification options*** in the dialog ***Modification options while design loading***.



If the button ***All modification options*** is active, the modification dialog will be switched on and will appear when loading a design.

Loading of designs via network using bar code control

Starting from the base screen of the T8 control unit:



Load design from network via bar code

- Scan the bar code ***Load design from network via bar code***.

⇨ The dialog ***Load design via network (bar code)*** is displayed.



- Scan the barcode that contains the design number or design name from your order form.

In the software settings are according to **Variant 1**, the design is now loaded directly, optimized and assigned to the machine. It can be embroidered directly.

If the software settings have been selected according to **Variant 2**, then the design can be loaded normally or rotated.



The design is loaded, modified, optimized and assigned to the embroidering machine according to the selection.

Label for use with bar code reader at the machine

- Print this label.
- Cut the label.
- Laminate the label.
- Position the label on the machine with bar code reader.



© 2018 ZSK Stickmaschinen GmbH
Printed in Germany

ZSK Stickmaschinen GmbH
Magdeburger Str. 38-40
D-47800 Krefeld
Germany

www.zsk.de
zsk@zsk.de